




Sony Vaio Fit SVF15N26CXB Fan Replacement

Replace the fan in the Sony Vaio Fit SVF15N26CXB to improve cooling efficiency in the laptop.

Written By: Althea McDavid



INTRODUCTION

The fan is necessary to prevent the laptop from overheating. This guide will show you how to properly remove the fan component in the Sony Vaio Fit SVF15N26CXB. Use the project mat to keep the screws organized.



TOOLS:


- [Anti-Static Wrist Strap](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Battery




- Remove the following ten screws from the bottom case of the laptop:
 - Two 6.5mm Phillips #00 Phillips screws.
 - Four 8.95mm Phillips #00 screws.
 - Four 6.25mm Phillips #00 screws.
- ⓘ The screws may be hidden underneath a rubber foot that can be removed with a spudger.

Step 2



- Use a plastic opening tool to separate the bottom cover from the laptop.
- Lift the lower cover and pull away from the laptop.

Step 3






- Remove the eight Phillips #00 screws from the battery:
 - Six 4.65mm screws.
 - Two 4.65mm screws.

Step 4





- Lift the battery up and pull it out of the laptop.

Step 5 — Fan



- Remove the four 4.58mm Phillips #00 screws from the cooling system.
- Unscrew the five Phillips #00 screws from the heatsink.
- ⓘ These screws will remain attached to the heatsink.

Step 6



- Disconnect the fan from the motherboard.
- ⓘ This connector should be pulled upwards, not outwards.
- Remove the fan unit.

To reassemble your device, follow these instructions in reverse order.