

Archived

Motorola Moto G4 Teardown

This guide is for educational purposes and...

Written By: Kierra Schau



INTRODUCTION

This guide is for educational purposes and should not be used as a repair guide.

TOOLS:

Tweezers (1)
Spudger (1)
T4 Torx Screwdriver (1)

Step 1 — Motorola Moto G4 Teardown





- Place your thumb in the indent located at bottom left corner of the back cover.
- The cover will pop up and begin to lift.
- Continue to slide your fingers up the sides to remove the back cover.



- Using <u>tweezers</u>, remove the gray plastic surrounding the camera lens.
- (i) There will be a lot of glue and you may have to pull hard on the plastic piece.





- With tweezers, slide under all sides of the lens to loosen it.
- Pulls the lens towards you to remove the lens.
- (i) There will be glue under the lens. You may have to pull hard to remove the lens.

 \triangle Do not pull too hard on the lens. Pulling hard on it can result in breaking the lens.





- Using the screwdriver equipped with the T4 head drill bit, begin unscrewing the screws on the back panel.
- (i) Keep the screws on a magnetic board or strip to not lose any of them.
- After all the screws are removed from the back panel, lift the back panel off.





- Using the tweezers, unhook the twisted red and black wire from under the black plastic pieces that are holding it down.
- Using the tweezers, disconnect the wire from its connective port.
- Use the spudger to lift the battery out.
- i The battery is glued down so you will have to use some force to pull it out.
- \triangle Be careful not to pull it too hard it could bend the battery.







Using the tweezers, slide them under the speaker and pull the speaker out.

The back of the speaker is magnetic. Be careful to not touch it t other parts of the motherboard.







- Using the tweezers, pull up on the clasp that is holding the motherboard down.
- Using the tweezers, pull up on the clasp that is connecting the motherboard to the front-facing camera.
- Using the tweezers, remove the red and black wiring from the bottom of the phone by the charging port.





• Using the tweezers pull up on the three corners of the motherboard until it comes out.