

Aquaris M5 Rear Camera Replacement

Use this guide to replace a malfunctioning rear...

Written By: Theo Mat



INTRODUCTION

Use this guide to replace a malfunctioning rear camera in you bq Aquaris M5.

TOOLS:

iFixit Opening Tool (1)
Phillips #00 Screwdriver (1)
Spudger (1)
Tweezers (1)

Step 1 — Back Cover



- Insert the tip of an iFixit opening tool between the back cover and the mid frame of the phone.
 - (i) Between the 2 SIM card slots is a good place to start.
- Slide the opening tool to the bottom of the phone, to snap out the plastic clips, connecting the back cover and mid frame.

Step 2



- Slide the opening tool back to the top of the phone, to disconnect all the clips on the edge.
- Slide around the corner and along the top edge, to also disconnect these clips.

Step 3



 Δ Be careful not to bend the back cover too hard to prevent some of the clips breaking.

- Grab the back cover by the loosened edge.
- Gently bend and twist the flexible back cover a bit to disconnect the remaining clips.
- Take off the back cover.

Step 4 — Battery



- i Damaging the liquid indicator sticker, on the middle most screw, will void the warranty of the phone.
- Unscrew the ten black 4mm
 Phillips #00 Screws from the mainboard shield.
- Unscrew the golden 3.4mm
 Phillips #00 screw on the middle-right side of the mainboard shield.

Step 5








- Insert the flat side of a spudger between the mainboard shield and the frame of the phone.
- Twist the spudger to lift up the mainboard shield.
- Remove the mainboard shield from the phone.

Step 6



- Use a spudger to disconnect the battery's flex cable from the mainboard.
- Pull of the sticker on the bottom side of the battery.
- Grab the sticker and lift it up to take the battery out of the phone.

Step 7 — Rear Camera



- Use the flat side of a spudger to disconnect the camera's flex cable.
- Use <u>Tweezers</u> to grab the camera and lift it out of the phone.

