



Hoover Power Scrub FH50150 Nozzle Replacement

This guide will show you how to take off the nozzle of the Hoover Power Scrub FH50150.

Written By: Anthony Margulis



INTRODUCTION

Nozzle that releases the water/solution and sucks up dirty water. Also where the hose can be attached/detached. This nozzle may need to be cleaned after usage, so removal is necessary.

Step 1 — Water Tank



- Unlatch the grey switch labeled “Tank Release”.

Step 2



- Gently pull on the water tank until it releases from the base.

Step 3 — Nozzle



- Lift the switch that was covered by removing the tank.

Step 4



- Pull the nozzle until out of place.

To reassemble your device, follow these instructions in reverse order.