



Hoover Power Scrub FH50150 Water Tank Replacement

This guide will show you how to replace the dirty water tank on the Hoover Power Scrub FH50150.

Written By: Leo



INTRODUCTION

This guide will show you how to replace the dirty water tank on the Hoover Power Scrub FH50150.

Step 1 — Water Tank



- Unlatch the grey switch labeled “Tank Release”.

Step 2



- Gently pull on the water tank until it releases from the base.

To reassemble your device, follow these instructions in reverse order.