Hasee Z7M-i78172D1 CPU Fan Replacement

A replacement guide on how to replace the CPU fan inside the Hasee Z7M-i78172D1.

Written By: Jake Decker

This document was generated on 2020-11-28 06:34:34 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 5

🔧 TOOLS:

- Phillips #0 Screwdriver (1)
- iFixit Opening Tools (1)

⚙ PARTS:

- 7mm Phillip's Head Screw (18)
- Plastic Back Panel (1)
- CPU Fan (1)

This document was generated on 2020-11-28 06:34:34 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 2 of 5

Step 1 — Rear Panel

- Use a #0 Phillips head screwdriver and unscrew the sixteen 7mm screws on the back of the device.

Step 2

- Use a plastic opening tool to take off the back plastic panel.

Step 3 — CPU Fan

- To take out the CPU fan it is necessary to disconnect the CPU fan cable. Use a plastic opening tool to remove the cable.

Step 4

- Use a #0 Phillips head screwdriver to remove the two 7mm screws holding the fan to the motherboard.

This document was generated on 2020-11-28 06:34:34 AM (MST).

Step 5

- Lift the CPU fan out and replace with the replacement fan.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 06:34:34 AM (MST).