



# Alcatel One Touch Pop 7 Speaker Replacement

This guide demonstrates how to replace the speaker within the Alcatel One Touch Pop 7.

Written By: Libby West



---

## INTRODUCTION

In the case that your device is not producing any sound, it may be necessary to replace the speaker completely. This guide shows you where the speaker is within your device and how to replace it!

---

### **TOOLS:**

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Back Cover



- Begin by opening SD port cover as this is the best location to start prying.

## Step 2



- Use the plastic opening tool to pry around the edges of the back cover until it pops off.



### Step 3 — Speaker



- Locate the speaker on the bottom left hand side of the back cover.

### Step 4



- Using the plastic opening tool, dig under the silver speaker to remove it from the back cover.

To reassemble your device, follow these instructions in reverse order.