



Sungale Cyberus ID707WTA Battery Replacement

This guide will allow the owner to successfully replace the battery.

Written By: Austin_Parkes



INTRODUCTION

This guide will show the steps involved in replacing the battery.

TOOLS:

- [Fingers](#) (1)
-

Step 1 — Battery



- Press firmly on lower portion of the back cover and slide the cover towards the bottom to remove cover.

Step 2



- Pull on the plug carefully until it releases from the port and simply pull the battery out after.

To reassemble your device, follow these instructions in reverse order.