

Samsung Galaxy J1 Midframe Replacement

This disassembly guide will assist in removing the midframe of the Samsung Galaxy J1.

Written By: Sean Kramer



INTRODUCTION

If you need to remove the midframe to gain access to internal components such as the motherboard, front camera, rear camera, and daughterboard, this guide will do the trick!



TOOLS:

- iFixit Opening Tools (1)
- Phillips #00 Screwdriver (1)

Step 1 — Midframe



- Insert a finger nail or plastic opening tool between the back cover and the device.
- Gently pry the rear cover off of the back of the phone.

Step 2





- Using a finger, pull the SIM card down out of its slot.
- Remove the SIM card.
- (i) The pictured device is missing the SIM card and battery.

Step 3



 Using a Phillips #00 screwdriver remove the eleven 3 mm screws.

Step 4







- Insert a plastic opening tool between the screen and the back of the device.
- Starting at the bottom of the device, gently slide the tool along the edges of the screen.
- Gently pry the main assembly from the midframe of the device.
- Mhen removing the main assembly, pry gently so as to not crack the glass screen or break any clips within the device.

To reassemble your device, follow these instructions in reverse order.