

Hover-1 Folding E-Scooter Brake Switch Replacement

How to replace the Hover-1 Folding E-Scooter brake switch.

Written By: Brittani Kealoha



This document was generated on 2020-11-28 06:56:50 AM (MST).

INTRODUCTION

This guide is designed to help you replace a broken or damaged brake switch. All you will need is a #0 and #2 Phillips screwdriver to remove the screws in this guide



TOOLS:

- Phillips #0 Screwdriver (1)
- Phillips #2 Screwdriver (1)

Step 1 — Brake Switch



- Twist the handle with the red level counterclockwise to remove it from the scooter's main body.
- You will need to twist the handle clockwise reattach it to the scooter's main body.

Step 2





- Remove the four 5 mm screws twisting counterclockwise with a Phillips #0 screwdriver.
- These screws are small and easy to lose.
- Mhen inserting for reassembly the screws twist clockwise to secure.

Step 3







- Remove the red brake switch by sliding it off the main body.
- Mhen putting the brake switch back make sure to align the tab with the throttle switch.

To reassemble your device, follow these instructions in reverse order.