



Front License Plate Installation

Installation of the factory front license plate holder.

Written By: Justin





TOOLS:

- [1/8" Drill Bit](#) (1)
- [11/32" Drill Bit](#) (1)
- [Cordless Drill](#) (1)
- [Painter's Tape](#) (1)
- [Digital Caliper](#) (1)
- [Sharpie](#) (1)



PARTS:

- [7P6 807 285 G](#) (1)
- [N0385494](#) (4)
- [#10 x 1/2" Stainless Steel Screws](#) (4)

Step 1 — Front License Plate Installation



- Gather your tools. Drill, Sharpie, Drill Bits, Painters Tape.
- Get the parts, too. The front license plate bracket and the 4 plastic spreader rivets.
- Don't forget the Touareg :)
- Use Painters Tape to mark your drill bits at 1/2" of depth - so you don't drill into the bumper too far.

Step 2



- Position the license plate frame and center it on the VW emblem and parking camera (below, if installed). You can use the vertical supports in the lower grill (hard to see in this pic) to assist in alignment.
- Hold the license plate frame in place using some painters tape.
- Using the Sharpie, mark the four holes that you'll be drilling.

Step 3



- Remove the frame for easier drilling.
- Using the 1/8" drill bit, drill four pilot holes in the center of each position.
- Finish the holes by enlarging them with the 11/32" drill bit.

Step 4



- Place the frame back into position.
- Install the four plastic spreader rivets.
- Ensure they are seated by using a socket (as shown) to ensure rivets are fully seated before pushing in the center pin.

This document was generated on 2021-02-28 12:45:43 AM (MST).

Step 5



- Tap the center pins of the rivets so they are flush with the rivet body.
- Use #10 x 1/2" Stainless Steel Screws to affix the plate to the mounting bracket. You can see slight indentations where the screws are to go. I drilled pilot holes first.
- Don't use the "standard" license plate hardware that is 3/4" long. Those screws appear to be long enough to hit the bumper when inserted.