# How to Repair a Ripped Dog Toy

Fix your dog toy by replacing the squeaker and sewing the hole back together.

Written By: Madelyn Bevens

This document was generated on 2020-11-28 07:16:00 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 1 of 6

## INTRODUCTION

Repairing a dog toy is something anyone with a needle and thread could do at home! This quick repair will save dog owners a lot of the money they spend on dog toys and a trip to the pet store. It's also good for the environment since there won't be as many dog toys being thrown out, so it's saving the environment from more garbage!

## TOOLS:

- Thread (1)
- Needle (1)

## PARTS:

- Ripped Dog Toy (1)
- Squeaker (1)
- Stuffing (1)
- Fabric Square (1)

This document was generated on 2020-11-28 07:16:00 AM (MST).

www.iFixit.com

## Step 1 — How to Repair a Ripped Dog Toy



- Remove any stuffing and the current squeaker from the toy.

## Step 2



- Turn the empty toy inside out through the biggest hole and inspect for other holes to repair.

This document was generated on 2020-11-28 07:16:00 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 3 of 6

## Step 3



- Place the fabric square facing the outside of the toy over the hole.

## Step 4



- Begin sewing the patch to cover the hole.
  - To do so pinch both layers of fabric and put the needle through the other side and pull it back out of the top.
  - ⓘ Repeat this process until you sew the lining of the square.

## Step 5



- Turn the toy right side out.

## Step 6



- Re-stuff the toy by evenly putting the stuffing back inside.

- When about half of the stuffing is put back, inside insert the squeaker and continue to add stuffing.

This document was generated on 2020-11-28 07:16:00 AM (MST).

© iFixit — CC BY-NC-SA                          www.iFixit.com                                    Page 5 of 6

**Step 7**



- To sew the last hole pinch the fabric together and insert the needle through the top side and pull through the bottom.

- *i* Repeat this process until the hole is gone.

To reassemble your device, follow these instructions in reverse order.