



# Milwaukee M12 2407-20 Outer Casing Replacement

Detailed guide to remove the service housing set (outer casing) on the Milwaukee M12 2407-20.

Written By: Allison Schieber



---

## INTRODUCTION

This guide will walk through the steps to remove the service housing set (outer casing) on the Milwaukee M12 2407-20.

---

### TOOLS:

- [T10 Torx Screwdriver](#) (1)
-

## Step 1 — Outer Casing



- Remove each of the seven 14mm Pan Hd. T-10 ST screws on one side of the housing assembly using the T10 screwdriver.

## Step 2



- Remove metal clip located at the base of the drill, where the battery is to be inserted.
- ⓘ You may need to use a spudger if the clip is too difficult to remove with your fingers.