



# Dell XPS M1330 Battery Replacement

How to replace a Dell XPS M1330 battery.

Written By: Kai Kapossy



---

## INTRODUCTION

Is your Dell XPS M1330 not turning on or not holding a charge properly? If so, here is a 2 step guide that will allow you to disassemble and replace the existing battery.



### PARTS:

- [Dell XPS M1330 Battery](#) (1)
-

## Step 1 — Battery



- Flip the laptop on its back, so that the underside is facing up.

## Step 2



- Push and hold the slide button to the left and unlock the mechanism.

## Step 3



- Lift the computer up and slowly pull the battery straight out from the device.

To reassemble your device, follow these instructions in reverse order.