



Casio fx-85DE Plus Battery Replacement

Written By: Tomato Head



Step 1 — Casio fx-85 Battery



- The battery compartment is located on the top right of the back, it is secured with a screw.
- Unscrew the screw.
- Take off the cover.

Step 2



- Remove the old battery
- Insert the new battery

Work through the steps in reverse order to reassemble your device.