



2011 Toyota Sienna Taillight Bulb Replacement

This guide will show you how to replace the taillight bulb in your 2011 Toyota Sienna.

Written By: Raymond Tran



INTRODUCTION

This is a guide for a taillight light bulb replacement for a 2011 Toyota Sienna. You should replace your taillight light bulb when you notice that your taillight bulb is burnt out or when it doesn't light up. To get the replacement part for your taillight light bulb you need to go to your local auto shop with your burnt out taillight light bulb. You ask the employee of the auto shop for a new taillight light bulb by showing them the burnt out taillight bulb and telling them that your car is the 2011 Toyota Sienna.

TOOLS:

- [Socket 10mm](#) (1)
- [Socket Wrench](#) (1)

PARTS:

- [Tail Light Bulb](#) (1)

Step 1 — Taillight Bulb



- Turn off your car before you start working on your car.

Step 2



- Open your trunk's door.

Step 3



- Pry open the plastics cover on your trunk's door to get to the taillight bulb.

Step 4



- To remove the light turn it counterclockwise and remove it from the socket.

Step 5



- When you attach the new the taillight bulb, make sure to clean it with a clean towel to remove any excess dust and oil.

To reassemble your device, follow these instructions in reverse order.