



# Western Digital Essentials HD Case Replacement

Only prerequisite guide for disassembling Western Digital Essentials HD

Written By: Gaetan



 **TOOLS:**

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Case



- Use a large plastic opening tool along the rear panel:
  - There are 4 clips to release.

## Step 2



- Slide the cover along the plastic frame.

To reassemble your device, follow these instructions in reverse order.