



Apple remote A1156 battery Replacement

Replace a dead battery in your remote

Written By: Ben Capehart



INTRODUCTION

Replace a dead battery in your remote



TOOLS:

- [Spudger](#) (1)
- [SIM Card Eject Tool](#) (1)



PARTS:

- [CR2016 Lithium Battery](#) (1)


Step 1 — Eject the battery



- Take a Sim Eject Tool or Spudger and push.
- Then it should slide right out.

Step 2 — Replace the Battery



 Make sure you have it right-side up!

To reassemble your device, follow these instructions in reverse order.