

Panasonic Camera DMC-FX07 Battery Replacement

You won't need any tools, this will show you how to take the battery out

Written By: Duncan Rutherford



This document was generated on 2020-11-29 04:11:28 PM (MST).

INTRODUCTION

I am going to show you how to take the battery out.

Step 1 — Battery





- The first step is to turn off the camera
- Next, locate the battery door on the bottom of the camera
- To open, slide the latch left, or towards the tripod mount
 - The door should spring open

Step 2







- Now that the door is open, release the spring clip on the right
 - The battery should pop out just enough so you can pull it out
- Pull the battery out.

To reassemble your device, follow these instructions in reverse order.