

Logitech M215 Top Cover Replacement

Replace the top cover.

Written By: Hannah Pate



INTRODUCTION

Use this guide to replace the top cover on your Logitech M215.

TOOLS:

۶

- Phillips #0 Screwdriver (1)
- iFixit Opening Picks set of 6 (1)
- Plastic Cards (1)

Step 1 — Remove the battery cover



- The battery compartment cover is located on the top of the mouse. The seam running horizontally across the mouse is the top of the cover.
- There is a button to pop off the cover. It is located on the bottom of the mouse. you may need to press hard on this button to pop the cover.
- If the button does not work, you will need to pry off the cover. You can use your fingernails or a
 prying tool in order to do this, as seen in the third image.



Step 2 — Remove old battery

 Remember to insert the new battery in the same orientation as the old one. The positive (plus) end should be facing away from the buttons.

Step 3 — Top Cover



- The pads on the underside of the mouse hide the screws. Remove these first. You may need to use your fingernails or a prying tool.
- There will be two 0.5mm phillips head screws. Both will be underneath the bottom two pads.

Step 4



 Pry the top cover off. You may need to use a pry tool to help.

To reassemble your device, follow these instructions in reverse order.