



# Torque King Electric RTR RC Monster Truck

## Casing Replacement

This guide serves as a prerequisite only and it shows how to remove the truck's casing.

Written By: Maximiliano Cortes



## INTRODUCTION

This guide does not require any tools.

## Step 1 — Casing



- From the top view, remove each of the four pins that hold the casing in place.

## Step 2



- Slowly pull the casing up to remove it.

To reassemble your device, follow these instructions in reverse order.