



Linksys EA9200 External Antenna Replacement

Following these simple steps you will be able to replace the broken antenna of your device.

Written By: wendy



INTRODUCTION

This guide will help you to replace any of your external antenna's. No tools or disassembly will be required for this guide.

Step 1 — External Antenna



- The device comes with three external antennas that use thumb screws.

Step 2



- Unscrew the broken antenna using your fingers for removal.

To reassemble your device, follow these instructions in reverse order.