



Casio Cassiopeia E-125 Back Up Battery Replacement

This guide shows you how to replace the back up battery.

Written By: Ryan Fernandez



INTRODUCTION

The E-125 uses a button cell backup battery in addition to the main battery. If left uncharged for an extended period, the backup battery will be exhausted, and all data may be lost.

This guide shows you how to replace this battery.

TOOLS:

- [Spudger](#) (1)

Step 1 — Back Up Battery



- Flip the device over to the back side.

Step 2



- Flip the switch to "BACK UP".

Step 3



- Remove the battery cover by pulling bottom section upwards as shown.

Step 4



- Insert a [Spudger](#) underneath the battery and pry upward to remove it.

Insert the replacement battery and follow this guide's steps in reverse to reassemble.