



# 2009-2015 Toyota Prius Brake Fluid Replacement

A video tutorial on how to change the brake fluid on a 2009-2015 Toyota Prius.

Written By: eCuration



## INTRODUCTION

The brake fluid should be replaced every two years or 20,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.

### Torque specs:

- 10 ft. lbs - bleeder screws

## Safety

If this is your first time working on a vehicle read our [safety tips](#) before proceeding.



### TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Wheel Chocks](#) (1)
- [Brake Bleeder Bottle](#) (1)
- [10mm Wrench](#) (1)
- [8mm wrench](#) (1)



### PARTS:

- [Brake Fluid](#) (1)

To reassemble your device, follow these instructions in reverse order.