Lenovo Yoga 3 11 SSD Replacement

Replace the SSD in your Lenovo Yoga 3 11.

Written By: Geoff Wacker

This document was generated on 2020-11-17 12:54:57 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 8

INTRODUCTION

Use this guide to replace the SSD in your Lenovo Yoga 3 11.

🔧 TOOLS:

- Phillips #00 Screwdriver (1)
- T5 Torx Screwdriver (1)
- Tweezers (1)
- iFixit Opening Tools (1)

This document was generated on 2020-11-17 12:54:57 AM (MST).

Step 1 — Lower Case

- Remove the eleven 6 mm T5 Torx screws securing the lower case.

- Gently lift the lower case up and away from the device.

Step 2 — Battery

- Remove the two 3 mm Phillips #00 screws securing the battery.

- ⓘ There are arrows on the battery indicating the location of the screws.

This document was generated on 2020-11-17 12:54:57 AM (MST).

Step 3

- Use a pair of tweezers to gently disconnect the battery connector.

Step 4

- Use a pair of tweezers to gently disconnect the speaker cable.

- Remove the wires from underneath the battery tabs using the tweezers.

This document was generated on 2020-11-17 12:54:57 AM (MST).

Step 5

- Carefully remove the battery from the device.

Step 6 — SSD

- Use a pair of tweezers to disconnect the motherboard-size of the trackpad ribbon cable. Gently lift up

the black tab, and the cable should come free from the ZIF connector.

Step 7

- Use a pair of tweezers to disconnect the keyboard ribbon cable from the motherboard ZIF connector. Gently lift up the white tab, and the cable should come free.

Step 8

- Use a pair of tweezers to disconnect the motherboard-side of the SD board ribbon cable. Gently lift up the black tab, and then ribbon cable should come free from the ZIF connector.

This document was generated on 2020-11-17 12:54:57 AM (MST).

Step 9

● Use the tweezers to unplug the USB port from the motherboard by gently lifting the white connector up from the black motherboard connector.

Step 10

● Use a plastic opening tool to gently pry up the screen cable from the motherboard.

Step 11

- Remove the single 2 mm Phillips #00 screw securing the SSD.

- Gently lift the SSD up and out of the device.

To reassemble your device, follow these instructions in reverse order.