



Mio Alpha 2 Charging Pins Replacement

A guide on how to replace the charging pins on a Mio Alpha 2 watch.

Written By: Stefan Tracogna



INTRODUCTION

If your Mio ALPHA 2 heart rate monitor watch is not charging properly, it is possible that the charging pins need to be replaced. This guide will teach you how to remove the charging pins. You will need small tools to remove the cover on the back of the device. These tools will also need to be used to remove the charging pins. There are many small parts, so it is important to be in an environment where they will not be lost.

TOOLS:

- [JIS #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Charging Pins



- Remove the four 6.7mm JIS #00 screws from the back cover.

Step 2



- Remove the gold coils from the bottom of the pin. Remove the washer from the pin with the spudger.

Step 3



- Pop the pins out one at a time using the spudger.