

Lenovo ThinkPad Yoga 260 Repair Battery Replacement

If your battery is not functioning properly,...

Written By: Daniel Fernandez



INTRODUCTION

If your battery is not functioning properly, this guide will highlight the steps on how to replace it.

TOOLS:

Phillips #1 Screwdriver (1) iFixit Opening Tool (1)

PARTS:

00HW027 - Lenovo Laptop Battery - Genuine (1)

Step 1 — Back Cover



- *i* Ensure the device is off and unplugged.
- Remove the stylus from its port and set aside.

Step 2





- Using a Phillips #1 screwdriver, gently unscrew the eight 1.3 mm Phillips #1 screws until you hear an audible click.
- *i* The screws will not separate from the bottom cover when loose.

Step 3






- (i) The bottom cover is attached via several plastic clips located around the edges of the bottom cover.
- Using a plastic opening tool, gently pry the bottom cover from the laptop.
- Work the plastic opening tool around the edges of the bottom cover undoing all of the plastic clips, as shown in the picture.

Step 4





• Place your fingers around the edges of the cover and remove it.

Step 5 — Battery







- Fold back the plastic cover to access the battery connection.
- Remove the battery connection using your two index fingers.
 - (i) Gently separate the connectors.

Step 6







- Unscrew the two 1.3 mm Phillips #1 fasteners using a Phillips #1 screwdriver and set them aside.
- Lift the battery free from its mounting and remove it.

To reassemble your device, follow these instructions in reverse order.