



Thrustmaster Ferrari 458 Spider Racing Wheel motherboard Replacement

This guide will show you how to replace the motherboard of Thrustmaster Ferrari 458 Spider Racing Wheel

Written By: Mohammed Alsogair



INTRODUCTION

Use this guide to replace the motherboard of your Thustmaster Ferrari 458 Spider Racing Wheel.

TOOLS:


- [JIS #1](#) (1)
 - [2.5 mm Hex Key](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Bottom Cover




- Remove the black 10mm using a JIS #1 screw driver.
- ⓘ There are 12 screws.
- ⓘ Two of the screws are deep inside the device you might need to use a slim screwdriver.
- ⓘ In the picture you see a plastic opening tool instead of screw driver because we did not have our screw driver when we were taking the picture.

Step 2



- Remove the two 10mm black screws on the top of device using a Hex 2.5mm Key. Only the two outside screws.
- Gently pull apart both halves of device to access inside.

Step 3 — Motherboard



- Using a small plastic opening tool, gently pry up the white connector that connects the USB cable to the board.
- Cut the black cable as close to the board as possible.
- Remove the three screws using PH2 screw driver.

To reassemble your device, follow these instructions in reverse order.