


Alienware M11x Display Assembly Replacement

Written By: darrius



INTRODUCTION


In this guide, we will be showing you how to remove and replace the Display Assembly.



TOOLS:


• Phillips #0 Screwdriver (1)

Step 1 — Introduction




- MARNING: Before working inside your computer, read the safety information that shipped with your computer.
- CAUTION: To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface (such as a connector on your computer).
- NOTE: Dell or Alienware does not guarantee compatibility or provide support for hard drives from sources other than Dell.
- NOTE: If you are installing a hard drive from a source other than Dell or Alienware, you need to install an operating system, drivers, and utilities on the new hard drive.

Step 2 — Loosen the Screws




 Loosen the two captive screws that secure the hard-drive assembly to the computer base.

Step 3 — Disconnecting the Hard-Drive




 Using the pull-tab, pull the hard-drive assembly to disconnect the harddrive assembly from the connector on the system board.

Step 4 — Lifting the Hard-Drive Assembly




 Lift the hard-drive assembly out of the computer base.

Step 5 — Removing the Screws from the Hard-Drive



 Remove the four screws that secure the hard drive to the hard-drive bracket.

Step 6 — Removing the Bracket




 Lift the hard drive away from the hard-drive bracket.

Step 7 — Placing the Hard-Drive




 Place the **NEW** hard drive in the hard-drive bracket.

Step 8 — Replace the Screws




 Replace the four screws that secure the hard-drive to the hard-drive bracket.

Step 9 — Placing the Hard-Drive




 Place the hard-drive assembly in the computer base.

Step 10 — Connecting the Hard-Drive Assembly



 Use the pull-tab to push the hard drive assembly and connect it to the connector on the system board.

Step 11 — Securing the Screws



 Tighten the two captive screws that secure the hard-drive assembly to the computer base.