

Motorola MBP667CONNECT Circuit Board Replacement

This guide will show users how to replace the circuit board for the Motorola MBP667CONNECT.

Written By: Jordan Webb



This document was generated on 2020-11-28 07:18:36 AM (MST).

INTRODUCTION


In the case of damage or a non-functioning camera on the baby monitor, this guide will show users how to disassemble their camera in order to replace the circuit board.



TOOLS:

- Phillips #1 Screwdriver (1)
- Spudger (1)

Step 1 — Circuit Board








- Remove the two 5 mm Phillips #1 screws on the back of the camera.
- Use a nylon spudger to remove the casing.

Step 2










- Remove the brackets by the speaker on the front side of the camera using the metal spudger.
- Continue to use the metal spudger to carefully disconnect remaining brackets from casing.
- Remove the two 5mm Phillips #1 screws on the backside of the camera.

Step 3








- Use the nylon spudger to remove the circuit board from the plastic casing for the backside of the camera.
- Remove the two 5 mm Phillips #1 screws on the black circle receiver housing.
- Now that the black circle is detached, use a nylon spudger to remove the white plastic circle from the casing.

Step 4





You will now be able to carefully pull the receiver wire through the gap in the casing.

To reassemble your device, follow these instructions in reverse order.